7/25/2019 Network Issues

Network Issues

This page describes troubleshooting network issues with the Controller and Printer that will not show an error on a controller/printer screen or via a printer stack light.

#	Issue Description	Customer Troubleshooting Steps
NI1	Controller or Printer not connected to internet	1. Contact your network administrator to troubleshoot these issues. Ensure Ethernet cables are plugged into their appropriate ports, particularly on the Controller, on which Port A is an internet input and Port B is an output for connection to a dedicated printer LAN. Please view the Network Access section of the Facility Requirements Guide for more information. PORT B PORT B 2. If you are unable to solve network issues, contact 3D Systems Service.

7/25/2019 Network Issues

#	Issue Description	Customer Troubleshooting Steps	
NI2	Everything is connected properly; but Controller does not find printers over network	 Printer may need a new IP address if DHCP is turned on. Go to the module's network settings by going to Status >	